


## Removing and installing parking aid control unit -J446- - Sportback

- When renewing control unit select “Replacement” function for appropriate control unit in “Guided Fault Finding” or “Guided Functions” → [Vehicle diagnostic tester](#).

### Removing

- Switch off ignition and take out ignition key.
- Remove right luggage compartment side trim → [Rep. gr.70](#).
- If fitted, unplug electrical connectors -2- and -3-.
- Release retaining clip -arrow- and remove trailer detector control unit -J345--item 1- from frame.



- Unplug electrical connectors -2- and -3-.
- Release clip -arrow- and remove parking aid control unit -J446--item 1- from mounting frame.

### Installing

Install in reverse order, paying attention to the following:

Parking aid control unit -J446- must be re-encoded after renewing → [Vehicle diagnostic tester](#).

- Install luggage compartment side trim (right-side) → [Rep. gr.70](#).

