

4 Fuel filter

⇒ v4.1 iew - fuel filter", page 130

⇒ a4.2 nd installing fuel filter", page 132

4.1 Exploded view - fuel filter

⇒ v4.1.1 iew - fuel filter, A5 up to model year 2011, A4 up to model year 2012", page 130

⇒ v4.1.2 iew - fuel filter, A5 from model year 2012 onwards, A4 from model year 2013 onwards", page 130

4.1.1 Exploded view - fuel filter, A5 up to model year 2011, A4 up to model year 2012

1 - Fuel line

- Press release tab on connection piece to disconnect ⇒ page 124

2 - O-ring

- Renew

3 - Flange

4 - Fuel delivery unit

5 - Fuel filter


- Removing and installing ⇒ page 132

6 - Earth wire

- Attach to retaining plate

7 - Retaining plate for fuel pressure regulator

- With earth connection



4.1.2 Exploded view - fuel filter, A5 from model year 2012 onwards, A4 from model year 2013 onwards